

# Workflow

## MopFloat® CR



STEP 1: Let the operating lever be lowered by the weight of the mop frame. Liquid is automatically pre-dosed.



STEP 2: Open the mop frame without touching it and pick up the mop.



STEP 3: Pick up the prepared amount of liquid with the mop.



STEP 4: Carry out the wiping process.



STEP 5: Drop the mop without touching it. Repeat STEP 1 to 5.



**You can find more  
workflows in our  
downloads:**

[pfennig-reinigungstechnik.com/  
en/service/downloads](https://pfennig-reinigungstechnik.com/en/service/downloads)

**The  
Home of  
Clean**