

Pre-preparation

EasyMop CR®



STEP 1: Pour cleaning solution into the EasyMop CR® system box.



STEP 2: Load 10-12 mops into the EasyMop CR® system box with the backing material facing upwards.



STEP 3: Close the lid (snap in on all four sides), turn the EasyMop CR® system box upside down and wait 10 minutes. Turn the box back and open the lid.



STEP 4: Open the mop frame without touching it.



STEP 5: Pick up soaked mop without touching it.



STEP 6: Carry out the wiping process.



STEP 7: Drop the mop without touching it and repeat STEP 5 to 7.



**You can find more
workflows in our
downloads:**

[pfennig-reinigungstechnik.com/
en/service/downloads](https://pfennig-reinigungstechnik.com/en/service/downloads)

**The
Home of
Clean**