

Workflow

MopFloat® GMP



STEP 1: Pour the cleaning solution into the 25 litre stainless steel container.



STEP 2: Let the operating lever be lowered by the weight of the mop frame. Liquid is automatically pre-dosed.



STEP 3: Open the mop frame without touching it.



STEP 4: Pick up the mop without touching it.



STEP 5: Pick up the prepared amount of liquid with the mop.



STEP 6: Carry out the wiping process.



STEP 7: Drop the mop without touching it. Repeat STEP 2 to 7.



**You can find more
workflows in our
downloads:**

[pfennig-reinigungstechnik.com/
en/service/downloads](https://pfennig-reinigungstechnik.com/en/service/downloads)

**The
Home of
Clean**