

Workflow

Ringo® GMP flat wringer



STEP 1: Place the MopJump® pick-up aid and mop in the MopTen. Pour the cleaning solution into the 25 litre stainless steel container.



STEP 2: Pick up the mop without touching it.



STEP 3: Immerse the mop in the cleaning solution and swivel off the edge.



STEP 4: Press the mop in the Ringo® GMP flat wringer to the desired moisture level.



STEP 5: Carry out the wiping process.



STEP 6: Drop the mop without touching it and repeat STEP 2 to 6.



**You can find more
workflows in our
downloads:**

[pfennig-reinigungstechnik.com/
en/service/downloads](https://pfennig-reinigungstechnik.com/en/service/downloads)

**The
Home of
Clean**